The fitting guide for camera by Dicapac

– caution : please take off your uv, pl, etc filters. It makes scratches on Dicapac uv filter and it causes rainbow color on your photos.

model	DiCAPac — Compact cameras							Mirrorless	DSLR CAMERAS	
	WP-ONE	WP-510	WP-711	WP-710	WP-570	WP-610	WP-H10	WP-S3	WP-S5	WP-S10
CANON	[IXUS] 30, 40, 50, 55, 60, 65, 70, 75, 80IS, 85IS, 90IS, 95IS, 100IS, 100HS, 105, 107, 110IS, 115HS, 120IS , 125HS, 130, 132, 135, 140, 200IS, 210, 210is, 220HS, 230HS, 240HS, 255HS, 300HS, 310HS, 330, 400, 430, , 500, 700, 750, 800IS, 850IS, 860IS, 870IS, 900Ti, 950IS, 960IS, 970IS, 980IS, 990IS, 1100HS , i7-zoom, i, ii, i5-zoom, iis, V3, V2 [IXY] L , L2, L3, L4, 10, 10IS, 20IS, 25IS, 30, 30s, 30a, 50, 55, 60, 70, 80, 90, 95IS, 110IS, 120, 140, 200a, 200F, 210IS, 220IS, 300a, 320, 400, 400F, 450, 500, 510IS, 600, 630, 700, 800IS, 810IS, 820IS, 830IS, 900IS, 910IS, 920IS, 930IS, wireless, 1000, 2000IS, 3000IS [Powershot] E1 ,N ,N100, ELPH 150 [Powershot A] 480, 490, 495, 800, 810, 1100, 1200, 1400, 2200, 2300, 2400IS, 2500, 2600, 3000IS, 3100IS, 3200, 3200IS, 3300IS, 3400IS, 3500IS, 4000IS [Powershot S] 90, 100, 110, 120, 200, 230, 330, 400, 410, 500 [Powershot SD] 10, 20, 30, 40, 100, 110, 200, 300, 400, 430, 450, 500, 550, 600, 630, 700IS, 750, 770IS, 780, 780IS , 790IS, 800IS, 850IS, 870IS, 890IS, 900, 940IS, 950IS, 960, 960IS, 970, 970IS, 980IS, 990IS, 1000, 1100, 1200IS, 1300IS, 1400IS , 3500IS, 4000IS			[Powershot A] 100, 200, 300, D10	[Powershot] G7, G7X, G9, G15, G16, SX100IS, SX110IS, SX120IS, SX200, SX200IS, 210IS, SX220HS, SX230HS, SX240HS, SX270HS, SX280HS, SX600HS, SX700HS [Powershot A] 610, 620, 650 [Powershot SD] 4500IS	[Powershot] SX50HS, SX130IS, SX150IS, SX160IS, SX170IS ,SX510HS, G10, G11, G12	[Powershot] S3IS, S1IS, G1, G1X, G2, G3, G5, G6, G1X MARK 2	[Hybrid EOS] M, M2 Powershot SX400IS, SX500IS, SX510IS	[DSLR] EOS 100D, 300D, 350D, 400D, 450D, 500D, 550D, 600D, 650D, 700D, 1000D, 1100D, 1200D, [Rebel] SL1, T3, T3i, T4i, T5, T5i, Hi EOS kiss F, X2, X3, X4, X5, X50, X6i, X7, X7i, X70, DIGITAL X, N [Powershot] S5IS, SX10IS, SX20IS, SX30IS, SX40IS	[DSLR] EOS 5D, 5D MARK 2, 5D MARK 3, 6D, 7D, 7D MARK 2, D30, D60 [Rebel] T3, Rebel T3i, DIGITAL, 10D, 20D, 20Da, 30D, 40D, 50D, D30, D60, 60D, 60Da, 70D
CASIO	[Exilim] EX-S 5, 7, 8, 10, 12, 100, 200, 500, 600, 600D, 770, 880, EX-N 1, 10, EX-ZR 10, 20, 50, 100, 150, EX-ZS 5, 10, 15, 20, 26, 30, 35, 100, 150, 180, EX-FC 100, 200S, 400S, EX-FH 100, 150, EX-H 5, 10, 15, 30, EX-JE 10 EX-Z 2, 3, 4, 5, 6, 8, 9, 10, 16, 19, 20, 26, 29, 30, 33, 35, 37, 40, 50, 55, 57, 60, 70, 75, 77, 80, 85, 90, 100, 110, 120, 150, 155, 200, 250, 270, 280, 300, 330, 350, 370, 400, 450, 500, 550, 600, 680, 700, 750, 770, 780, 800, 850, 1000, 1050, 1080, 1200, 1200SR , 2000, 2300, 3000 QV-R 3, 4, 40, 41, 51, 61, 100, 1100	[Exilim] EX-P A 600, 700, E 500, 510, 550, 900			[Exilim] EX 10, 100 SC100, EX-H 20G, 60, EX-ZR 500, 510, 700, 800, 850, 1000, 1100		[Exilim] EX-FS 20, EX-P 50S, EX-FH 25			
FUJIFILM	[Finepix] A 100, 130, 150, 170, 180, 203, 220, 230, 235, 303, 310, 330, 340, 345, 500, 510, 600, 610, 700, 800, 850 AX 200, 230, 280, 300, 350, 355, AV 110, 100, 130, 150, 200, 205, 250, 255, F 10, 11, 20, 30, 47, 420, 440, 450, 455, 460, 470, 480, 650, 31fd,40fd, 45fd, 47fd, 50fd, 60fd, 70EXR, 80EXR, 72EXR, 100fd, 200fd, 200EXR J 10, 12, 15, 15fd, 20, 27, 28, 29, 30, 32, 40, 50, 110W, 150W, 250JV, 100, 110, 150, 200, 205, 210, 1004 , JX 200, 250, 280, 300, 305, 350, 500, 520, 580, 700 , JZ 300, 500, S 4000, V 10	[Finepix A] 610, 820, 900, 920	[Finepix] Z 1, 2, 3, 5fd, Z100fd, Z200fd, 300, Z300fd	[Finepix] REAL 3D W1, 3D W3, XP 30, 33WP, 35, 37, 70, 80, 90, 110, 700EXR, 800EXR, 900EXR, 909EXR, SL 10, 22, 30, 33, AV 120, 202	[Finepix] F 300EXR, 500EXR, 550EXR, 600EXR, 660EXR, 750EXR, 800EXR, 820EXR, 850EXR, 900EXR, 1000EXR, XF 1, XQ 1, T 200, 300, 350, 400, 500, 550, 560, JV 300		[Finepix] SL 280 , S 1000fd, 1500, 1600, 1700, 1800, 2000HD, 2800z, 2950, 2990, 4000, 4300, 4500, 4800, 8600	[Hybrid] X E1, E2, A1, M1, T1, 10, 20, 30, 100, 100S, 100T, Pro1		[DSLR] Finepix IS Pro, S S Pro
KODAK	[PIXPRO] FZ 41, 51 [Easyshare] ONE,JOC L108, Mini, FZ 41, 51, MD 30, C 142, 143, 180, 182, 183, 190, 195, 533, 613, 643, 653, 663, 743, 763, 813, 913, 1013, 1033, 1093IS, 1530, LS 633, 743, 753, 755, M 200, 320, 340, 341, 380, 381, 530, 531, 532, 550, 575, 577, 580, 583, 753,763, 853, 863, 873, 883, 893IS, 1033, 1063, 1073IS, 1093IS, 5350, V 530, 550, 803, 1003, 1073, 1233, 1253, 1273	[Easyshare] Z885, 1275, C 330, 340, 360, 875, CX 6230, 6330, 7220, 7330, 7430, 7530, DX 4330, 4530, 6340, 6440, 7440, 7630, LS 443	[Easyshare] V 570, 610, 705, silce	[Easyshare] MD 590	[Easyshare] FZ 151	[Easyshare] Z 915, 950, 1285, 1485IS	[Easyshare] C 1012IS, ZD710, Z612, Z650, Z712IS, Z710, Z740, ZB12IS, ZB612IS, Z980, Z981, Z101SIS , DX7590, DX6490, P712, P850, AZ 251, 361, 362	[Hybrid] PIXPRO S-1	[PIXPRO] FZ 501, 521, 522 [Easyshare] AZ 501, 521, 522	
RICOH	[Caprio] R1, R50, RZ1, RR630, RR660, RR770				[Caprio] R 3, 4, 5, 6, 7, 8, 10, 40, GX100, GX200 CX1, CX2, CX3, CX4, CX5, CX6		[Caprio] Hybrid GXR			
SAMSUNG	[Kenox, Digimax] A 4, 5, 6, 7, 40, 50, 400, 55W, D 4, 5, 6, 7, 60, 103, 860, L50, 55W, 60, 70, 73, 74wide, 700, 730, 830, Q 1, 2, 25wide, S 85, 500, 600, 630, 700, 730, 760, 800, 830, 860, 1000, 1030, 1060, 1070, U-CA 3, 4, 5, V 3, 4, 5, 6, 10, 20, 700, 800, X 1, 15wide, 60,70 [Cyber] 410, X80 [VLUU] BL 1050, CL 80, DV 100, 150F, 300F, ES 10, 15, 17, 20, 25, 28, 30, 55, 60, 65, 70, 71, 73, 75, 80, 90, 95, IT 100, L 1, 100, 110, 200, 201, 210, 301, 310w, M 300w, 310w, MV 800, 900F, NV 8, 10 ,15, 20, 30, 40, 24HD, 25HD, 100HD, 106HD, 404 PL 20, 50, 51, 55, 60, 65, 70, 80, 90, 100, 101, 120, 121, 150, 170, 171, 200, 210, SH 100, SL 30, 50, 102, 201, 202, 310, 420, 502, 620, 630, 720, 820, TL 90, 100, 34HD, 205, 210, 220, 225, 240, 320, WB 30F, 1000, 2000	[Kenox, Digimax] 360, 370, 420, 430, 530, Cyber 300, 400, D 60, 370, 430, 470, 510, 530, 610, 3000, 3100, 4000, L 85, V 50, 70, X-85	[Kenox, Digimax] #1, 1mp3, 11pmp, I 5, 50mp3, 6, 6pmp, 7, 70, 8, 80, 85, 100, K 50, 60, D 5125 [VLUU] CL 65, L 83T, NV 3, 4, i8, i85, i7, i100, PL 10, ST 10, 1000, TL 9		[Kenox] S 10 [VLUU] M 77, NX i70, i80, 9, TL 10, 100, 1000	[Kenox] EX1 [without ring, 카메라링 제거 후 사용 가능] 2F NX EK-KC120, EK-KC120, EK-GC110, S 1050, 850 [VLUU] WB 35F, 50F, 110, 150F, 210, 250F, 350F, 500, 510, 550, 600[HZ30W], 650, 700, 850F	[VLUU] NV 5, 7ops, 11, NX 100, 200, WB 750		[Hybrid] NX 30, 100, 200, 210, 300, 300M, 1000, 1100, 2000, 3000, mini, EK-GN120, EK-KC120, EK-GC110,200, EK GN120, KC120, GC110, GC200, WB 1100F, 2100, 2200F DSLR GX 1L, 1S, 10, 20, NX 5, 10, 11, 20	[DSLR] GX 1L, 1S, 10, 20, NX 5, 10, 11, 20
NIKON	[Coolpix] 3700, 4100, 4600, L 2 , 3, 4, 6, 10, 11, 12, 14, 15, 16, 18, 19, 20, 21, 22, 23, 24, 28, 30, S 01, 02, 200, 203, 210, 220, 230, 500, 510, 520, 550, 560, 570, 600, 610, 610C, 620 , 630, 640, 700, 710, 800C, 810C, 2500, 2600, 2800, 3000, 3100, 3300, 3500, 3600, 4000, 4100, 4150, 4300, 5100, 5200, 5300, 6000, 6100, 6150, 6200, 6300, 6400, 6500, 6600, 6700, 6900	[Coolpix] 2200, 3200, 4200, 5200, 5600, 5900, 7600, 7900, C-500ZOOM, L 1, P 1, 2, 50, 60, 5000, 5100, S 810c, 8100		[Coolpix] A 100, 1000pj, 1100pj, 1200pj, 2500, 3500	NIKON 1 [Hybrid] P 5000, 5100, 6000 [Coolpix] A, L620, L620, S 6800, 8000, 8100, 8200, 9100, 9200, 9500, 9600, 9700, S10	[Coolpix] L P7000, 7100, 7800, S 7000, 7100, 7800	[Coolpix] L 100, 110, 120, 820, 830, P 80	[Hybrid] AW1 S1, S2, V1, V2, V3, J1, J2, J3, J 1, 2, 3, 4, S 1, 2, V 1, 2, 3, P 100	[DSLR] D 40, 40X, 50, 60, 80, 90, 3000, 3100, 3200, 3300, 5000, 5100, 5200, 5300, 7000, 7100, F6 P520, 530, 600	[DSLR] D3, F, 3X, 3S, 4, 4S, 70S, 100, 200, 300, 300S, 500, 600, 610, 700, 750, 800, 800E, 810, DF
OLYMPUS	[Camedia] VH210, 410, SH21, VR 320,330,370, C 60z, 310Z, 315Z, 370, 480, 470z,X500, 500, 500z, 600, FE 20, 25, 26, 35, 45, 46, 47, 48, 130, 140, 150, 160, 170, 180, 200, 210, 220, 230, 240, 250, 270, 280, 290, 300, 310, 320, 330, 340, 350, 360, 370, 3000, 3010, 4000, 4010, 4020, 4030, 4040, 4050, 5000, 5010, 5020, 5030, 5035, 5040, 5050, 5500, VG 120, 130, 140, 145, 150, 160, 165, 170, 180, 190, X 775, 785, 790, 815, 820, 875, 895, 920, 930, 940 [u, Stylus] 10, 15, 20, 25, 30, 40, 40digital, 110, 300, 400, 500, 600, 700, 780, 800, 820, 830, 840, digital S, Mini, Verve S, T100, 110 X 1, 2, 3, 350, 450, 550, 775, 785, 790, 815, 820, 825, 840, 845, 855, 875, 880, 895, 920, 930, 935, 940, 60z, 310z, 315z,370, 480, 500z, 710, 740, 750, 760, 810, 1000, 1200, D630z, 1010, 1020, 1060, 5000, 5010, 7000, 7010, 7020, 7030, 7040, 7050, 9000, 9010, T100, VR320, 370	[Camedia] SP 320, 350, C 1z, 2z, 40, X 200, 250 u, Stylus 535, 545, 595z	[Camedia] SP 700 u, Stylus 700sw, 720sw, 725sw, 730, 795sw, 850sw, 1030sw, 1040, 1050sw, 1070	[Camedia] C AZ 1, IR 300, 500, u 6010, Tough 3000, 6000, 6010, 6020, 8000, 8010, 550WP, FE 120, 150, 160, 170, 180 u, Stylus X 700	[Camedia] SH 1, 25MR, 50, SZ 14, 15, 31MR, XZ 10	[Camedia] XZ1, 2, SZ10, 11, 16, 20, 30MR, C 70z, 700, 730, 740, 745, 750, 755, 760, 770	[Camedia] SP 590uz, 570uz, 565uz, 560uz, 550uz, 510uz, 500uz, 600uz, 610uz, 620uz, 720uz, 800uz, 810uz, 820uz, C 7070wz, 5060wz, 4000z, 4040z, 700uz, 720uz, 730uz [Mini] 2, OM-D E-M1, 5, 10	[Hybrid] E-P1, 2, 3, 5, 6, 7, E-PL1, 2, 3, 5, 6, E-PM1	[DSLR] E30, 300, 330, 400, 410, 420, 500, 510, 520, 620 Camedia SP 590uz	[DSLR] E1, 3, 5
PANASONIC	[Lumix DMC] F 1, 2, 3, 4, 7, FH 1, 2, 3, 5, 6, 7, 10, 20, 22, 25, 27, FS 2, 3, 4, 5, 7, 10, 11, 12, 14, 15, 16, 18, 19, 20, 21, 22, 23, 24, 28, 30, 5, 7, 8, 9, 10, 12, 30, 33, 35, 36, 37, 38, 40, 48, 50, 55, 60, 65, 66, 68, 70, 75, 77, 78, 90, 100, 150, 180, 500, 520, 550, 580, 700 LS 1, 2, 5, 70, 80, 85, LZ 8, 10, S 1, 2, 3, SZ 1, 3, 8, 9, XS 1, 3, ZR 1, 3, ZX 1, 3	[Lumix DMC] LC 50, 70, 80, LZ 1, 2		[Hybrid DMC] FZ 2, 10 [Lumix DMC] LF 1, 2, 3, 5, 7, 8 FT 1, 2, 3, 10, 25 FH 3D1	[Lumix DMC] LX 1, 2, 3, 5, 7, 100 TZ 1, 2, 3, 4, 5, 6, 7, 8, 10, 15, 18, 20, 22, 30, 35, 40, 55, 60, ZS 1, 3, 5, 6, 7, 8, 10, 15, 20, 25, 40, LF 1, LZ 7		[Lumix DMC] FZ 5, 35, 38, GF 2C, F GF2C		[DSLR DMC] L 1, 10, FZ 10, 28, 45, 70, 200, G 1, 2, 3, 4, 5, 6, 10, GH X5, S1	
PENTAX	[Optio] A 10, 20, 30, 36, 40, E 10, 20, 30, 40, 50, 60, 70, 80, 90, H 90, 110, P 70, 80, RS 1000, 1500, S 1, 4, 5n, 6, 7, 30, 40, 45, 50, 55, 60, 330, 330RS,430, 430RS, S, S4, S4i, S5i, S5n, S5z, S6, S7, SSi, SV, Svi, T 10, 20, 30, L 70, LS 465, 1000, 1100, M 10, 20, 30, 40, 50, 60, 90, NB 1000, V 10, 15, 20		[Hybrid] K 10, 20, 30, 60 Optio GH WP, WPi, Z10, WS80	[Optio] Q 80, 90	[Optio] GH 750Z, RZ 10, 18, VS 20	[Optio] MX 1		[Hybrid] K 1, Q S1, 7, 10,	[DSLR] *ist D, DL, DS, DL2, DS2, K 3, 5, 7, 10D, 20D, 30, 50, 100D, 100D Super, 110D, 200D, 500, R, X, 5	
SONY	[Cybershot DSC] J10, N 1, 2, P 100 , 120 , 150 , 200, S 30, 35, 40, 50, 55, 70, 80, 85, 90, 110, 150, 170, 180, 190, 200, 220,230, 290, 300, 310, 320, 330, 350, 360, 370,380 ,390, 500, 510, 520, 530, 550, 560, 600, 610, 620, 630, 650, 690, 700, 730, 750, 780, 800, 930, 950, 980, 2000, 2100, 3000 [W] 30, 35, 40 50, 55, 70, 80 85, 90, 100, 110, 130, 150, 170, 180, 190, 200, 220, 230, 290, 300, 310, 320, 330, 350, 360, 370, 380, 390, 510, 520, 530, 550, 560, 570, 580, 610,620, 630, 650, 670, 690, 730, 800, 810, 830, [WX] 1, 5, 7, 9, 10, 30, 50, 70, 80, 100, 150, 220, 300, 350	[Cybershot DSC] [P] 1, 2, 5, 7, 8, 9, 10, 71, 72, 73, 92, 93, [S] 60, 90 [W] 1, 5, 7, 12, 15	[Hybrid NEX] 1, 5, 7, 9, 10, 20, 30, 55, 66, 100V, 200V, 300V [Cybershot DSC] T 1, 2, 3, 5, 7, 9, 10, 11, 20, 30, 33, 50, 70, 75, 77, 90, 99, 100, 110, 200, 300, 500, 700, 900 TX 1, 2, 3, 5, 7, 9, 10, 11, 20, 30, 33, 50, 70, 75, 77, 90, 99, 100, 110, 200, 300, 500, 700, 900	[Cybershot DSC] [W] 31, 32, 51	[Cybershot DSC] H 55, 70, HX 50V, 60V, RX 100, M2, M3	[Cybershot DSC] H 3, 10, 20, 30, 50	[Cybershot DSC] H 5, 7, 9, 50, V3	[Hybrid NEX] 3, 3N, 3NY, 3NL, 5, 5R, 5N, ST, 5TY, 5TL, 6, 6L, 6Y, 7, 7K, C3, F3, a7, 7s, 7R, 5000, 6000 RX 1R	[DSLR] SLR(alpha α) A 7,7 II (A 7 2), 7 S, 7R, 33, 35, 37, 55, 57, 58, 65, 77, 99, 100, 200, 230, 300, 350, 380, 390, 450, 500, 550, 560, 580, 700, 850, 900, 3000, 5000, 6000 [Cybershot DSC] HX 300, 400, 400V, RX 10	
ETC	[BenQ] DC C40, C50, DC E53, 520, 510 [Epson] L-300 , 400 [Hitachi imega] HDC-531 [Hyundai] DC-4300 [Hyundai] DC-4300, [Leica] C-Lux1, Lux2, Lux3 [Mach power] DX-550 [Minox] DC8111 [Polaroid] PDC3370 [Praktica] DCZ4.3 [Toshiba Alegretto] 3310, 3330 [Rollei Prego] DP4200, DP8300 , 6300 , 5300, DT3200	[BenQ] alpha DC 5330, S30 [Hitachi imega] HDC-331 [Hyundai] HD-530 [Premier] DC2302, 3306, 5330 [Praktica] DCZ4.4 [Toshiba] PDR5300 [Kenko] Z510 [Kokom] KDC-330	[Che-ez] Foxz 2, moni-me		[BenQ] alpha 10, 20, 30	[Leica] Dlux4, Dlux4, Dlux5, Dlux20, X1, typ 109 [Sigma] DP1, DP1X, DP2, DP2X	[Leica] M9, V-LUX30	[Leica] V-LUX, V-LUX2, V-LUX3	[Leica] DSLR DIGILUX 3	[Sigma DSLR] SD14, SD15, SD1